

# BOUNCIN' BUDDIES LLC



Vineland Area  
(856) 692-2828

[info@webringthebounce.com](mailto:info@webringthebounce.com)



## **EMERGENCY EVACUATION PROCEDURE**

The Lessee, before operating the ride, must familiarize him/herself with the ride's entrance/exit as well as escape hatches. In the unforeseeable event that power is interrupted and the ride begins to lose air, the Lessee should guide all the riders to calmly and orderly leave the ride via the entrance/exit.

All rides that have permanent roofs feature Escape Hatches on the roof. The Lessee may choose to have the riders exit the ride through these easily accessible escape hatches. All rides, such as the combo module, that have convertible roofs offer the Lessee the alternative of allowing the riders to exit the ride through the wide openings around the roof.

If the Lessee determines the weather conditions warrant closing down the ride or in the event of a power failure, the following procedure shall be observed:

1. Stop riders from entering the device, including parents.
2. Riders in the bouncer shall be told to leave through the entrance in an orderly manner, as rushing may intimidate smaller and more timid children.
3. Riders on the lower section of the climb shall be advised to climb back down and exit through the bouncer portion.
4. Riders on the upper part of the climb and the slide itself shall be instructed to proceed to the slide and exit the normal way. Apply the normal slide rules of one person on the slide at a time.
5. It takes close to two minutes before the slide starts to sag noticeably and, even then, a rider may safely slide down and exit. Evacuation time is 30-45 seconds

Weather conditions that permit closing the ride down include but are not limited to:

1. Rain (any water may result in electric shock)
2. Lightening (with or without rain)
3. Snow / Sleet / Hail
4. Winds exceeding 25 mph
5. Hurricane / Tornado